



INSTALLATION INSTRUCTIONS


HIGHLAND GARDEN PLANTER

HARDWARE AND PARTS INCLUDED (IMAGES ARE NOT 1:1 SCALE)


	DESCRIPTION	QTY	PART IMAGE
a	Long Panels	2	
b	Short Panels	2	
c	End Caps	4	
d	Base Plate	1	
e	Liner	1	

	DESCRIPTION	QTY	PART IMAGE
g	L-Key T-25	1	
h	* M5-8, 12MM screws	see below	
	14" x 18" x 18"	40	
	14" x 36" x 18"	44	
	36" x 36" x 18"	56	
	14" x 72" x 18"	52	
	14" x 18" x 30"	56	
	14" x 36" x 30"	60	
	36" x 36" x 30"	72	
	14" x 72" x 30"	68	

* each kit includes 5 extra screws




Step 1.
Remove all parts from the box and lay out on soft or protective surface.
Recommended: low torque power tool.



HIGHLAND GARDEN PLANTER


Step 2.

Fasten a long panel to the base plate.




Step 3.

Fasten short panels to the base plate.




Step 4.

Align the long panel corners with the short panels and fasten bottom screws.



Step 5.


Fasten screws to the mid-level corner holes.



HIGHLAND GARDEN PLANTER


Step 6.

Rotate planter upside-down and install the end caps on all four corners.




Step 7.

Rotate back upright and install the end caps on all four corner extrusions.



Step 8.

Place the liner inside the planter.



HIGHLAND GARDEN PLANTER

Step 9.


Fill with desired contents.



IF APPLICABLE FOR HIGH PLANTERS

Note: PVC Foam Board included in shipping

Recommended solution to prevent planter from tipping, use "cinder blocks" (note: not included with shipping)



Other recommended solution to prevent planter from tipping:

- Sand
- Rocks
- Gravel

Filler height must be a min-max range(8"-11").

